



NAIA RATTAN DOME PENDANT



PO Box 4522 Dandenong South, Victoria Australia 3164
164-168 Atlantic Drive, Keysborough, VIC Australia 3173

www.earlysettler.com.au

www.earlysettler.co.nz

90018032



90018034 Pendant
220-240V AC
50/60Hz



Assembly And Safety Instructions

Turn off mains power to install this fitting

Unpack the rattan shade and suspension set components.

A: Attach the bracket (4) to ceiling with screws provided. If the ceiling is concrete, drill holes and insert the supplied plastic plugs then screw on the metal bracket

B: Pass the cable up through the cover (3) plate so that the cable exits the ceiling canopy.

C: Pass cable wire through bracket and attach to household wiring with the insulator connection block. (5)

Position canopy on ceiling and attach retaining screws 3

D: Insert the bulb

Maintenance and Care

- Never tamper with lamp holder or electrical parts
- Allow bulb to cool before replacement
- Clean with a dry soft cloth.

It is recommended that a qualified electrician installs this lighting product

**BULB WATTAGE FOR THIS LAMP IS E27 60 WATT INCANDESCENT,
OR AN EQUIVALENT E27 LED OR CFL BULB**



Parts List

- 1: RATTAN SHADE
- 2: SUSPENSION CABLE
- 3: CEILING CANOPY
- 4: FIXING BRACKET
- 5: WIRE CONNECTOR BLOCK

